



Image comparison app

Build image library with golden samples

Compare products to your own reference photos. Choose side-by-side view, alternate display or split view mode.



With reference photos, we can quickly see deviations in products. It's great

TAGARNO

Results

Increase efficiency by comparing

Increase operator efficiency by using photos of golden samples as a visual guide instead of long product specification texts. Add new photos to the library at any point.

How to

Capture, save and recall photos



Capture reference photo

- ✓ Save a photo of current sample
- ✓ Move the reference indicators to a suitable location
- ✓ If needed, crop the photo to only save relevant area
- ✓ Save the photo as a template for later use



Recall photos

- ✓ Select a template/reference photo from the dropdown menu
- ✓ Choose how you want the reference photo displayed
- ✓ Delete template when it's no longer needed
- ✓ [Read more about Image comparison app](#)

TAGARNO

tagarno.com