



Image comparison app

# Build image library with own photos

Compare products to your own reference photos. Choose side-by-side view, alternate display or split view mode.



**With reference photos, we can quickly see deviations in products. It's great**

**TAGARNO**

## Results

# Increase efficiency by comparing

Increase operator efficiency by using photos of approved products as a visual guide instead of long product specification texts. Add new photos to the library at any point.

## How to

# Capture, save and recall photos



### Capture reference photo

- ✓ Save a photo of current sample
- ✓ Move the reference indicators to a suitable location
- ✓ If needed, crop the photo to only save relevant area
- ✓ Save the photo as a template for later use



### Recall photos

- ✓ Select a template/reference photo from the dropdown menu
- ✓ Choose how you want the reference photo displayed
- ✓ Delete template when it's no longer needed
- ✓ [Read more about Image comparison app](#)

**TAGARNO**

[tagarno.com](https://tagarno.com)