



PNG reference app

Use visual guides in inspection

Inspection graphs with GO and NO GO areas for every product or reference photos of what to look out for during inspection. You can create anything you want.



With the images as a visual guide, there's fewer human mistakes. It's great

TAGARNO

Results

Be consistent and reduce preparation time

When pairing your inspection graphic with a preset, you'll use the same settings again and again. Letting the microscope adjust to the settings saved in the preset is also much faster than doing it manually.

How to

Create and link to microscope settings



Create your photo



The app accepts PNG photos as inspection graphics



We recommend using free image editor programs like GIMP or Pixlr E that can create PNG files with a transparent background



Create any and as many 1920x1080 pixel photos as you want



Link it to your settings



Select a photo and adjust microscope and light settings as needed



Save your photo and settings as preset



Recall a preset and the microscope automatically displays the photo and changes microscope settings



[Read more about PNG reference app](#)

TAGARNO

tagarno.com